



JULI BIS 2



(D) Montageanleitung

(NL) Handleiding voor de montage

(TR) Montaj talimati

(F) Notice de montage

(CZ) Montážní návod

(GB) Assembly instructions

(HU) Szerelési útmutató




(PL) Instrukcja montażu

(RU) Инструкция по монтажу


(IT) Istruzioni di montaggio

(SK) Návod na montáž


(RO) Instrucțiuni de montaj



x1




x4








x16



x1



0-6








Service • Assistenza • Dienstverlening • Serwis • Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denimire • Isim • Название

Nr • No. • N° • Номер • Č • Sz

Type • Tipo • Tipus • Typ •
Тип • Тір



A




x...

B




x...

C



x...

D



x...